





# **T701i**

#### **Pro1 Technologies**

P.O. Box 3377 Springfield, MO 65808-3377 **Toll Free :** 888-776-1427 **Web:** www.pro1iaq.com **Hours of Operation:** M-F 9AM - 6PM Eastern

Page


# Table of Contents

Table of Contents1Thermostat Operation2-3Thermostat Quick Reference4Thermostat Warranty Information5

Una version en español de este manual se puede descargar en la pagina web de la compañia.



**Equipment damage hazard** Do not operate the cooling system if the outdoor temperature is below 50 °F (10 °C) to prevent possible compressor damage.




1) LCD Display

Glow in the Dark Light Button



Temperature Setpoint Buttons



#### 5 System/ User Button

# 1) LCD Display

See page 2 for details about display and read out icons.

# ) Glow in the Dark Light Button

The glow in the dark light button will self illuminate for several hours after exposure to ambient light. This button turns on the display light when pressed.

# **3** Temperature Setpoint Buttons

Press the + or - buttons to select the desired room temperature.

# 4) Fan Button:


Select **ON** or **AUTO**. **ON** will run the fan continuously. **AUTO** will run the fan only when the heating or cooling system is on.

Note: Some systems may have fan control disabled.

## **(5)** System Button:

Select the operation mode of your HVAC system. Selecting **HEAT** will put your system in heating mode. Selecting **COOL** will put your system in air conditioning mode. Selecting **OFF** turns the system off.

#### **Thermostat Quick Reference**



## Cut Out For Warranty Registration

