


Installation Guide

- To ensure the maximum output, a Supply Injection Tube has been factory installed in the **RIGHT** bottom tapping (Left side – Return - contains a red colored plug).
- Supply Injection Tube
- If you choose to connect Return at the right side and Supply to the left bottom tapping, remove plastic tube from the right side and install opposite (left) side prior to hooking up water connections. Tube can easily be removed without tools (your finger will do)!
-  The distance between wall and tapping is adjustable from 2-1/2" to 3-1/2".
Recommended floor clearance 6".
- If a one-pipe injection valve - such as Heimeier M 3876 "Single entry (1-pipe) valve for towel warmer" - is being used, remove and discard tube.
- All (4) brackets must be secured to studs or other supports of sufficient strength for towel warmer PLUS water.

Bracket installation

Towel Warmer Installation Guide Flores C (Noblesse NB)